VPort 36-1MP Series

Quick Installation Guide

Third Edition, October 2013



P/N: 1802000360011

Overview

The VPort 36-1MP Series is the world's first rugged IP camera that can withstand environmental temperatures ranging from -40 to 75°C without a heater or fan. It is an industrial-grade, H.264 box-type IP camera that combines HD resolution (1280 x 720), advanced IVA (Intelligent Video Analysis) technology, and de-mist technology to enhance surveillance system efficiency while delivering state-of-the art video quality. Optional housing and PT scanner accessories are available for indoor and outdoor installation.

The VPort 36-1MP Series is designed to be compatible with C/CS mount lenses to meet any viewing angle and distance requirement. With a built-in removable IR-cut filter and automatic color mode switching, the VPort 36-1MP Series is suitable for day-and-night use. Highly-tuned ROI (Region of Interest), BLC (Black Level Control), and WDR (Wide Dynamic Range) functions enable the VPort 36-1MP Series to produce exceptionally clear images. The VPort 36-1MP Series can encode analog video into both H.264 and MJPEG video streams and can transmit up to 3 independent video streams (2 in H.264, and 1 in MJPEG) simultaneously. Advanced video encoding technology enables the camera to support up to 30 fps for each of the H.264 and MJPEG streams.

Package Checklist

Moxa's VPort 36-1MP Series is shipped with the following items. If any of these items is missing or damaged, please contact your customer service representative for assistance.

1 VPort 36-1MP series camera (one of models below)

1 VPOIT 30-1MP series calliera (one of filodels below)		
Model Name	Description	
VPort 36-1MP	VPort 36-1MP, POE, 0 to 60°C operating	
	temperature	
VPort 36-1MP-T	VPort 36-1MP, POE, -40 to 75°C operating	
	temperature	
VPort 36-1MP-IVA	VPort 36-1MP, POE, 0 to 60°C operating	
	temperature, 1 IVA license	
VPort 36-1MP-IVA-T	VPort 36-1MP, POE, -40 to 75°C operating	
	temperature, 1 IVA license	
VPort 36-1MP-DM	VPort 36-1MP, POE, 0 to 60°C operating	
	temperature, de-mist function	

 Screw handle acce 	essory package	
Inner hexagon	C/CS mount adapter ring	5-pin terminal block
screwdriver for		for DI and relay
tightening/ loosening		
lens holder		
	0	

3-pin terminal block for for power input RS-485 DX+ and DX-

- · Quick installation guide
- Documentation & software CD (includes User's Manual, Quick Installation Guide, and VPort Utility)
- Warranty card

NOTE Check the model name on the VPort's side label to determine if the model name is correct for your order.

NOTE This product must be installed in compliance with your local laws and regulations.

Features

Sensor: 1/2.7" HD progressive scan CMOS **Lens:** C/CS mount lens (lens not included)

Auto Iris Type: DC drive

Illumination (low light sensitvity):

Color: 0.2 lux at F1.2
B/W: 0.05 lux at F1.2
Synchronization: Internal

Gamma Correction: 0.45 or 1.0 (default 0.45)
White Balance: ATW/AWB (range: 3200 to 10000°K)
Dynamic Range: Color: 100 dB; B/W: 110 dB
Auto Electronic Shutter: 1/30 to 1/25000 sec.

Electronic Shutter: 1/50, 1/100, 1/250, 1/500, 1/1000, 1/2000,

1/4000, 1/10000 sec.

S/N Ratio: 50 dB (Gamma, Aperture, AGC OFF; DNR ON)
ICR Control: Auto (light sensor control) or DI control
DNR: Built-in DNR

WDR: Level 1-8/Off
AGC Control: On/Off
Flickerless Control: On/Off
Auto Exposure: On/Off

Image Rotation: Flip, Mirror, and 180° rotation

Image Setting: Manual tuning for brightness, saturation, contrast, and

sharpness

Video Compression: H.264 (ISO/IEC 14496-10) or MJPEG

Video Outputs: Ethernet

Video Streams: Up to 3 video streams (2 x H.264 and 1 x MJPEG)

• Stream 1: H.264, 1280 x 720 resolution (max.)

Stream 2: H.264, 720 x 480 resolution (max.)
Stream 3: MJPEG, 720 x 480 resolution (max.)

Note: Streams 2 and 3 must be at the same resolution

Video Motion Detection: 3 independently configurable motion areas

Scheduling: Daily repeat timing schedule

Imaging: JPEG snapshots for pre/trigger/post alarm images

Video Recording: Event recording stored on the SD card

Email/FTP Messaging: Automatic transfer of stored images via email or FTP when alerted

Custom Alarms: HTTP event servers for setting customized alarm

actions

Pre-alarm Buffer: 24 MB video buffer for JPEG snapshot images

Advance Software Features:

- DynaStream[™] for automatic adjustment of frame rate
- 3 privacy mask areas provided
- ROI (Region of Interest) configuration for up to 3 areas

Safety: UL 60950-1, EN 50121-4, NEMA TS2, Class 1 Division 2

(Pending), Atex Zone 2 (Pending)

EMI: FCC Part 15, CISPR (EN 55022) class A


EMS: EN 61000-4-2 (ESD), Level 3 EN 61000-4-3 (RS), Level 3 EN 61000-4-4 (EFT), Level 3 EN 61000-4-5 (Surge), Level 3 EN 61000-4-6

(CS), Level 3 EN 61000-4-8, EN 61000-4-11

Shock: IEC 60068-2-27 Freefall: IEC 60068-2-32 Vibration: IEC 60068-2-6 Warranty: 5 years

Product Description

Top View



Bottom View



NOTE The product is shipped with the mounting bracket fastened to the bottom of the camera. However, the bracket can be removed and repositioned to the top of the camera, depending on your deployment requirements.

- Auto Iris Socket: Plug the auto-iris cable from camera lens into this socket to use the auto-iris function.
- Lens Holder: The lens holder is designed for CS mount lenses; a C/CS adaptor must be used to mount C lenses. For details, see the HW installation section of this manual.
- SD Card Slot: Remove the SD card slot cover and insert an SD card for disconnection/event local storage.
- Mounting Bracket Screw Holes: For fastening mounting brackets.
- Reset Button: Use a pointed object to push in the reset button to reboot. Push and hold the button until the system reboots to restore factory defaults.

Back Panel View



- 1. 5-pin terminal block for DI and relay connection
- 2. 2-pin terminal block for RS-485 pin connection
- 3. RJ45 port for PoE/non-PoE connection
- 4. Ground screw for connecting a grounding wire
- 5. 3-pin terminal block for power input
- LED indicator to show network and system status. Green indicates normal operation.
- LED indicator to show power status. Green indicates normal operation.

NOTE The VPort 36-1MP can be powered by a 12-32 VDC or 18-30 VAC power input, or Power over Ethernet (PoE, 802.3af). For power redundancy, use DC or AC power together with PoE.

Hardware Installation

Step 1: Remove the lens cover.



Step 2: Loosen the lens holder screw with the torx screwdriver.



Step 3: Remove the lens holder.



NOTE Be sure to loosen the screw affixing the lens holder in step 2 before trying to remove the lens holder. The lens holder may be too tight to loosen if the screw is not loosened first.

Step 4: Screw the lens holder to the lens you are going to use.



NOTE Be sure to screw the lens holder to the lens on the right side. The side of the lens holder with the groove should be facing the lens; the side without the groove should be facing outwards.

Step 5: Screw the lens and lens holder to the VPort 36-1MP.

NOTE We strongly suggest that you perform this step while viewing live video from the camera via a web browser for instant feedback on when to stop. Be sure not to tighten the screw all the way, or the lens holder may remain fixed to the camera when you remove the lens.

NOTE You can tighten the lens holder screw (see Step 2) to fix the position of the lens holder and lens.

NOTE You do not need to use the C/CS mount adaptor ring if you are using the VPort 36-1MP series with an optional lens purchased from Moxa. It is only required to mount the lens with the adaptor ring if you are using a C mount type lens.

Step 6: Power on your VPort 36-1MP.

NOTE The VPort 36-1MP can be powered by a 12-32 VDC or 18-30 VAC power input, or Power over Ethernet (PoE, 802.3af). For power redundancy, use DC or AC power together with PoE.

Software Installation

Step 1: Configure the VPort 36-1MP's IP address.

When the VPort 36-1MP is first powered on, the POST (Power On Self Test) will run for a few moments (about 30 seconds). The network environment determines how the IP address is assigned.

Network Environment with DHCP Server

For this network environment, the unit's IP address will be assigned by the network's DHCP server. Refer to the DHCP server's IP address table to determine the unit's assigned IP address. You may also use the Moxa VPort and EtherDevice Configurator Utility (edscfgui.exe), as described below:

Using the Moxa VPort and EtherDevice Configurator Utility (edscfgui.exe)

Run the **edscfgui.exe** program to search for the VPort. After the utility's window opens, you may also click on the **Search** button to initiate a

search.

When the search has been completed, the Model Name, MAC address, IP address, serial port, and HTTP port of the VPort will be listed in the utility's window.



You can double click the selected VPort, or use the IE web browser to access the VPort's web-based manager (web server).

Non DHCP Server Network Environments

If your VPort 36-1MP is connected to a network that does not have a DHCP server, then you will need to configure the IP address manually. The default IP address of the VPort 36-1MP is 192.168.127.100 and the default subnet mask is 255.255.255.0. Note that you may need to change your computer's IP address and subnet mask so that the computer is on the same subnet as the VPort.

To change the IP address of the VPort manually, access the VPort's web server, and then navigate to the **System Configuration** → **Network** → **General** page to configure the IP address and other network settings. Check the **Use fixed IP address** to ensure that the IP address you assign is not deleted each time the VPort is restarted.

Step 2: Access the VPort 36-1MP's web-based manager

Type the IP address in the web browser's address input box and then press enter.

Step 3: Install the ActiveX Control Plug-in

A security warning message will appear the first time you access the VPort's web-based manager. The message is related to installing the VPort AcitveX Control component on your PC or notebook. Click **Yes** to install this plug-in to enable the IE web browser for viewing video images.




NOTE For Windows XP SP2 or above operating systems, the ActiveX Control component will be blocked for system security reasons. In this case, the VPort's security warning message window may not appear. Users should unlock the ActiveX control blocked function or disable the security configuration to enable the installation of the VPort's ActiveX Control component.

Step 4: Access the homepage of the VPort 36-1MP's web-based manager.

After installing the ActiveX Control component, the homepage of the VPort 36-1MP's web-based manager will appear. Check the following items to make sure the system was installed properly:


- 1. Video Images
- 2. Video Information



Step 5: Access the VPort's system configuration.

To change the configuration, click **System Configuration** to view the system configuration overview page. **Model Name**, **Server Name**, **IP Address**, **MAC Address**, and **Firmware Version** appear on the green bar near the top of the page. Use this information to check the system information and installation.

For configuration details, check the User's Manual on the software CD.



Wiring Requirements



Safety First!

- Be sure to disconnect the power cord before installing and/or wiring your Moxa VPort 36-1MP.
- Calculate the maximum possible current in each power wire and common wire, and observe all electrical codes dictating the maximum current allowable for each wire size.
- If the current exceeds the maximum ratings, the wiring could overheat, resulting in serious damage to your equipment.

You should also pay attention to the following:

- Use separate paths to route wiring for power and devices. If power wiring and device wiring paths must cross, make sure the wires are perpendicular at the intersection point.
- You can use the type of signal transmitted through a wire to determine which wires should be kept separate. The rule of thumb is that wiring that shares similar electrical characteristics can be bundled together.
- Keep input wiring and output wiring separated.
- We strongly advise labeling the wiring to all devices in the system.

Specifications

Camera	
Sensor	1/2.7" HD progressive scan CMOS
Lens	C/CS mount lens
Auto Iris Type	DC drive (lens not included with product)
Illumination	Color: 0.2 lux at F1.2
	B/W: 0.05 lux at F1.2
Synchronization	Internal
White Balance	ATW/AWB (range: 3200 to 10000 °K)
Wide Dynamic	Color: 100 dB
Range	B/W: 110 dB
Electronic Shutter	AES: 1/30 to 1/25,000 sec
	Fixed: 1/50, 1/100, 1/250, 1/500, 1/1000, 1/2000,
	1/4000, 1/10000 sec
Gamma Correction	0.45 or 1.0 (default is 0.45)
S/N Ratio	50 dB (Gamma, Aperture, AGC OFF, DNR ON)
ICR control	Auto (light sensor control) or DI control
DNR	Built-in
WDR	On/Off
AGC Control	On/Off
Flickerless Control	On/Off
Backlight	On/Off
Compensation	
Auto Exposure	On/Off
Image Rotation	Flip, Mirror, and 180° rotation
Image Setting	Manual tuning of brightness, saturation, contrast,
	and sharpness

Video						
Video Compression	H 264 (ISO/IEC 144	196-1	n) or MIDEG		
Video Output	Via Ethe		70 1	5) 01 1451 EG		
Video Streams	Maximu MJPEG) Stream Stream	m of 3 video 1: H.264, m 2: H.264, m 3: MJPEG, r	nax. re	esolution 12 esolution 72	80x72 0x480	0
	Note: S	treams 2 and	13 mi	ist be the sa	me res	olution.
Video Resolution and FPS		NTSC Size	Max. FPS	PAL Size	Max. FPS	
	QCIF	176 x 120	30	176 x 144	25	
	CIF	352 x 240	30	352 x 288	25	
	VGA	640 x 480	30	640 x 480	25	
	4CIF	704 x 480	30	704 x 576	25	
		720 x 480	30	720 x 576	25	
	SVGA	800 x 600	30	800 x 600	25	
	HD	1280 x 720		1280 x 720		
	Up to 30	0/25 FPS for				streams
	at max.	resolution.		•		
Video Viewing	vide 3 pi Adji Tim Max con ROI	astream™ see frame rate rivacy mask ustable imagestamp and dimum of 10 nections (Region of 1	e auto areas je size text o simul	omatically provided and quality overlay Itaneous uni	, cast	
PTZ	Digital I					
Network	<u> </u>					
Protocols	DHCP, I	DP, HTTP, SN JPnP, RTP, R ./v2c/v3, DE L	RTSP,	ICMP, IGMP	v3, Qo	S,
Ethernet	1 10/10	OBaseT(X) E	therr	et port, RJ4	5 conr	nector
Standard	OnVIF					-
Local Storage						
SD socket	Standar	d SD socket	(SDF	IC)		
GPIO						
Digital input	High: -3	13V to +30V 30 to +3V				
Relay output	1, max.	24 VDC @ :	l A			
Serial Interface	1 6 11 1	l DO (2)				
RS-485	1 full-di	uplex RS-48	5 port	<u> </u>		
LED Indicators	T	- 16 41-				
STAT	1 .	s if the syst		octed proper	riy or r	not
Network		s or 100 Mbp	JS			
Power	Power c	n/off				
Input	12 VDC (PoE, 80	, 24 VDC, 24 02.3af)	1 VAC	or Power ov	er Eth	ernet
·		•				

Physical Character	istics
Housing	Metal housing, IP30 rated
Dimensions	78 x 65 x 150 mm
Installation	Wall mounting, ceiling mounting, pole mounting,
	corner mounting
	(You may need to purchase external housing and/or
	mounting accessories separately.)
Security	
Password	User level password protection
Filtering	By IP address
Authentication	802.1X
Encryption	SSL/SSH
Alarm	004,00
Intelligent video	Camera tampering, virtual fence, object counting,
Intelligent video	alert zone, missing object, loitering object (except
	for camera tamper, IVA functions are optional)
Video Motion	3 independently configurable motion areas
Detection	and y doming a dole motion dieds
Scheduling	Daily repeat timing schedule
Imaging	JPEG snapshots for pre/trigger/post alarm images
Email/FTP	Automatic transfer of stored images via email or
messaging	FTP as event-triggered actions
Custom Alarms	HTTP event servers and CGI events for setting
	customized alarm actions
Pre-alarm Buffer	24 MB video buffer for JPEG snapshot images
Environmental Lim	
Operating	Standard Models: 0 to 60°C (32 to 140°F)
Temperature	Wide Temp. Models: -40 to 75°C (-40 to 167°F)
Storage	-40 to 85°C (-40 to 185°F)
Temperature	,
Ambient Relative	5 to 95% (non-condensing)
Humidity	3,
Regulatory Approv	vals
Safety	UL 60950-1
,	EN 50121-4
	NEMA TS2
	Class 1 Division 2 (Pending)
	Atex Zone 2 (Pending)
EMI	FCC Part 15, CISPR (EN 55022) class A
EMS	EN 61000-4-2 (ESD), Level 3
	EN 61000-4-3 (RS), Level 3
	EN 61000-4-4 (EFT), Level 3
	EN 61000-4-5 (Surge), Level 3
	EN 61000-4-6 (CS), Level 3
	EN 61000-4-8,
	EN 61000-4-11
Shock	IEC 60068-2-27
Freefall	IEC 60068-2-32
Vibration	IEC 60068-2-6
Warranty	
Warranty period	5 years
Details	See www.moxa.com/warranty
•	· · · · · · · · · · · · · · · · · · ·

CPU: Pentium 4, 2.4 C	SH ₇	
	١١٢	
Memory: 512 MB of memory		
OS: Windows XP/2000 with SP4 or above, Windows Vista, Windows 7		
Browser: Internet Exp	olorer 6.x or above	
Multimedia: DirectX 9	.0c or above	
Software Utility		
li ii li	includes CGI commands, ActiveX Control, and API ibrary for customized applications or system ntegration for third third-party developers (the atest version of SDK is available for download from Moxa's website).	
Accessories		
Enclosure \	/P-CI701 (IP68 Indoor/Outdoor Housing)	
Brackets \	/P-CI800 (Wall Mount Bracket)	
	/P-CI815 (Pole Mount Bracket)	
	VP-3112MPIR (3.1 to 8 mm, F1.2, Day&Night)	
\	VP-1214MPIR (12.5 to 50 mm, F1.4 Day&Night)	

Minimum Viewing System Requirements

Technical Support Contact Information

www.moxa.com/support

 Moxa Americas:
 Moxa China (Shanghai office):

 Toll-free:
 1-888-669-2872
 Toll-free:
 800-820-5036

 Tel:
 1-714-528-6777
 Tel:
 +86-21-5258-9955

 Fax:
 1-714-528-6778
 Fax:
 +86-21-5258-5505

Moxa Europe: Moxa Asia-Pacific:

Tel: +49-89-3 70 03 99-0 Tel: +886-2-8919-1230 Fax: +49-89-3 70 03 99-99 Fax: +886-2-8919-1231